





EasyStand Evolv Medium, Large, XT Support Package Feature Descriptions




FEATURE	IMAGE	DESCRIPTION	MIN	MOD	MAX
Multi-Adjustable Foot Plates		Foot Plates adjust independently in height from 1"-5" (2.5-13cm) off floor, plantar/dorsi +/- 20°, and +15° toe out adjustment.	X	X	X
Secure Foot Straps		Velcro® and D-ring adjustment hold feet securely in place at ankle and toes. Must choose size in drop box.		X	X
Flip-Up Knee Pad		Height and depth adjustable, knee pads flip-up and out of the way during transfers.	X		




FEATURE	IMAGE	DESCRIPTION	MIN	MOD	MAX
Independent Knee Pads for Swing-Away Front- Size Medium & Large Frames ONLY		<p>For Size Medium and Large Frames ONLY, width range from center to center is 9"-13.5" (24-34cm). Depth range from front of seat is 1"-7.5" (3-19cm). Height range is +5" to -5.25" (+13 to -13cm) from seat pivot.</p>		X	X
Independent Knee Pads for Size XT Frame		<p>Width range from center to center is 9"-13.5" (24-34cm). Knee pad depth range from front of seat is 1"-7.5" (3-19cm). Knee pad height range is +5" to -5.25" (+13 to -13cm) from seat pivot.</p>		X	X
Planar Seat		<p>The Planar Seat for Size Medium is 16" W x 17.5" L (40.6 x 44.5cm). For Size Large and XT the seat is 19" W x 21.5" L (48.3 x 54.6 cm). Seat Height from Floor (Transfer Height) is 21.5" (55 cm) for Size Medium and Large Frames and 23.5" (60 cm) for Size XT Frame.</p>	X	X	X

FEATURE	IMAGE	DESCRIPTION	MIN	MOD	MAX
Easy Adjust Seat Depth		Roller bearing seat depth adjustment that allows for smoother seat depth adjustment. Seat Depth Range (from seat pivot) for Size Medium is 14" - 19" (36-48 cm), Size Large is 18"-23" (46-58cm) and Size XT is 19" - 24 " (48-61 cm).	X	X	X
Velcro® Positioning Belt		2" (5cm) wide positioning belt has a D-ring Velcro® closure, provides hip stability for user. Fits hip circumference of 26"-55" (66-140cm) OR 38"-67" (97-170cm). Must choose size in drop box.	X	X	X
Hip Supports		Supports the hips in symmetrical alignment from sitting to standing. Pad size is 4"x6" (10x16cm). Must choose width range of hip supports in drop box.		X	X
Removable Flat Back		Removable back releases with two knobs and provides rear access for patient lift transfers. Must choose height of back in drop box.	X	X	X

FEATURE	IMAGE	DESCRIPTION	MIN	MOD	MAX
Removable Contoured Back		Removable Contoured Back releases with two knobs and provides rear access for patient lift transfers. Must choose height of back in drop box.	X	X	X
Chest Strap		Velcro® and D-ring adjustment. Chest strap pad is 5”Wx19”L (13x48cm). Must choose size of strap in drop box.	X	X	X
Accessories Mounting Bracket		Required for attaching the chest vest, lateral supports, high mount chest vest bracket, and head support.		X	X
Lateral Supports with Curved Pads		Lateral Supports help to keep trunk in midline. Multiple adjustments, removable for transferring. Depth range is 3” (8cm). Height range is 4”-12” (10-30cm). Pad size is 4”x6” (10x15cm). Must choose width range in drop box		X	X

FEATURE	IMAGE	DESCRIPTION	MIN	MOD	MAX
Lateral Supports with Flat Pads		<p>Lateral Supports help to keep trunk in midline. Multiple adjustments, removable for transferring. Depth range is 3” (8cm). Pad size is 4”Hx6.25”W (10x16cm). Must choose width range in drop box.</p>		X	X
Black Molded Tray with Chest Pad		<p>Black Molded Tray with Chest Pad provides anterior support and a work surface. Adjustable in height and depth. Tray size is 21”x24” (53x61 cm).</p>	X		
Large Contoured Chest Pad		<p>Attaches to Black Molded Tray (pictured in row above) in MOD Support Package. Attaches to Shadow Tray in MAX Support Package. Replaces standard Chest Pad. Oval pad is 9.5”Hx15”W (24x38cm).</p>		X	X

FEATURE	IMAGE	DESCRIPTION	MIN	MOD	MAX
Chest Vest	 <p style="text-align: center;">X-Style Y-Style</p>	<p>Vest offers trunk support for midline positioning and support to keep shoulders back and stable as a foundation for head control. Must choose Neoprene® or Non-Stretch Fabric, Style, and Size in drop box.</p>			X
High Mount Chest Vest Bracket		<p>Moves mounting points for chest vest higher to secure shoulders in position.</p>			X
Shadow Tray	 <p style="text-align: center;">Black Molded</p> <p style="text-align: center;">Clear Acrylic</p>	<p>Height/Depth adjustable shadow tray. Height range is 6"-11" (15-27cm) from the seat. Depth range is 4"-20" (10-20cm) measured from the back to the front pad. Tray size is 21"Lx24"W (53x61cm).</p>			X

FEATURE	IMAGE	DESCRIPTION	MIN	MOD	MAX
Head Support	 <p>Head Support Short</p> <p>Head Support Tall</p>	<p>Head Support helps to maintain head in a well aligned midline position. For Short Head Support, height range from seat with a 15" back is 21"-30" (53-76cm) and with a 19" tall back it is 23"-32" (58-81cm). For Tall Head Support, height range from seat with a 15" back is 23"-32" (58-81cm) and with a 19" tall back it is 25"-34" (64-86cm). Must choose Short or Tall Head Support in drop box.</p>			X
Manual Hydraulic Actuator with Handle		<p>Allows user to manually move themselves from sitting to standing.</p>	X		
Adjustable/ Removable Actuator Handle		<p>Removable actuator handle adjusts the distance of reach to actuator handle to meet user's needs.</p>		X	X

FEATURE	IMAGE	DESCRIPTION	MIN	MOD	MAX
Swing-Away Front (Not available on Size XT Frame.)		On Medium and Large Size Frames, allows the tray and knee pads to swing away with minimal lifting, providing more room for assisted transfers. Not available on Size XT Frame.		X	X
5" Front Wheels and 5" Rear Locking Casters		Front wheels are fixed and roll forward and back. Back wheels are locking swivel casters	X	X	
5" Front Swivel Casters		Locking casters allow for easier steering and movement of stander. Back wheels are also locking swivel casters.			X